



FIS CA3 Fusion Splicer - Set up for Cheetah Splice-on Connectors

Turn off the Tension ("Pull") Test

- Select "Settings" from the Main menu.
- Change the "Pull" Test (#7) setting to "Off".

Fiber Settings for Cheetah SOC Splicing

The CA3 splicer will allow you to splice SOC's using any specific fiber setting or any Auto setting.

You can change the fiber settings by referring to the manual and selecting the Splice Menu from the Main Menu screen.

Sleeve Oven Settings

- Set the heater Mode to "25mm" (#9). This selection is preset to 170 degrees; 30 seconds; 10 seconds.

You can change this setting or any other heater setting by following the instructions in the Manual supplied with your splicer.

Install Heater Block Accessory

Your splicer kit comes with a heater block accessory for SOC's. To install the accessory:

- In the closed position, grasp the left side of the heater cover and slide the end piece gently to the left until it slides off the oven.
- Slide on the SOC the separate heater block accessory being careful to align the pin with the corresponding hole in the heater cover top.

FIBER INSTRUMENT SALES INC

161 CLEAR ROAD
ORISKANY, NY 13424
800-5000-FIS (347)

